

# Model 4740 Asphalt Ignition Oven

## Quick Start Guide

### Important Installation and Start-up Guide

*\*Please be sure to read the operator's manual thoroughly in addition to this guide.*

- **The oven must be installed in a well-ventilated room with access to a fume hood or other suitable ventilation system.** If the exhaust duct shipped with the oven is used, locate the oven no more than 4.6 m (15 ft) from the exhaust outlet. Be sure to insulate the exhaust duct sufficiently. Follow local codes for proper installation of the exhaust outlet.
  - The overall diameter of all ducts should be 4 inches or greater and the length should not exceed 4.6 m (15 ft) from the top of the oven to the point of exhaust
- **Locate the oven no more than 1.2 m (4 ft) from the required electrical power source** (see Appendix C in manual). Ensure that the distance does not place stress on the power cord. The power source must be wired by a qualified electrician.
- **Place the oven on a level, sturdy, fireproof surface.**
- **Locate the oven at least 15 cm (6 in.) from other vertical structures.**
- **Do not restrict the airflow in and around the bottom of the oven.**
- **Do not install the oven near combustibles, such as gasoline or paint.**
- **Keep all cords away from the top and sides of the oven.**